Vertikaler Einbau

1. Skalenwechsel

Bitte beachten Sie die Bedienungsanleitung:

- für Typ 10..GL/GLR und Typ 11..G/GR Seite 3-2
- für Typ 115.. Seite 3-3

2. Anpassung der Korrelatoranzeige

Auf der Anschlussleiste (Gegenstecker) müssen die folgenden Pins miteinander verbunden werden:

- Typ 10..GL Pin **18** und **19**, Seite 2-1
- Typ 11..G Pin **18** und **19**, Seite 2-1
- Typ 115.. Pin **18 a** und **19**, Seite 2-1 bis 2-3
- Typ 10..GLR Pin **3** und **12**, Seite 2-1
- Typ 11..GR Pin **3** und **12**, Seite 2-1

Details finden Sie in der Bedienungsanleitung auf den angegebenen Seiten!

Vertical Installation

1. Scale change

Please refer to manual:

- for type 10..GL/GLR and type 11..G/GR see page 6-2
- for type 115.. see page 6-3

2. Adaption of the correlation display direction

An additional connection has to be made on the connector (counter plug):

- Typ 10..GL between pin **18** and **19**, see page 5-1
- Typ 11..G between pin **18** und **19**, see page 5-1
- Typ 115.. between pin **18 a** und **19**, see page 5-1 to 5-3
- Typ 10..GLR between pin **3** and **12**, see page 5-1
- Typ 11..GR between pin **3** and **12**, see page 5-1

For details see the operating manual at the pages listed above!