RTW
RADIO-TECHNISCHE
WERKSTÄTTEN GMBH

Additional information RTW PCM-Set 2

When using the RTW PCM-Set 2 only as transmitter for the video signal there is no level monitoring on the 701 and on a built in peakmeter in AD 2.

To get level indication you have to link the jacks VIDEO IN 2 and VIDEO OUT 2 and set the VIDEO switch in position 2, both on AD 2. The outsending signal you get out of jack VIDEO OUT 1.

Another way to indicate the input signals is to feed in the audio signal the normal way and additional to the ext. meter inputs of the AD 2. On a built in RTW PPM you can measure the input signals when switching the METER switch in ext.-position.